

4 Foot Comfort Park Avenue



Hardware



Recycled Plastic Bases



Cedar Slats



4ft Comfort Park Avenue

PARTS LIST: (Quantity for one 4' bench)

QTY	ITEM
2	2" x 4"x 4' Bench Slats with 4 holes
5	2" x 4"x 4' Bench Slats with 2 holes
2	Pre Drilled Bench Supports
18	1/4 x 3 1/2 Zinc Plated Lag Screws
18	Zinc Plated Washers

TOOLS NEEDED FOR INSTALLATION:

Socket set with a 7/16" Socket

INSTALLATION INSTRUCTIONS:

1. Check Parts list to verify all items.
2. Place washers on the zinc plated lag screws and start them in the pilot holes on the bench slats.
3. Run the lag screws through the pilot holes in the slats letting them extend through approximately 1/4".
4. Place the slats on the supports and line up the screws with the pre drilled holes in the supports. Start with one of the front boards and then one on the top boards (to allow you to get the bench square). Finish with the remaining bench supports in any order.
5. Using the 7/16" socket tighten the lag screws securing the slats and the supports.
6. **DO NOT OVERTIGHTEN THE LAG SCREWS! THIS MAY CAUSE THE PLASTIC BENCH SUPPORTS TO STRIP OUT!**



www.jayhawkplastics.com

6 Foot Comfort Park Avenue



Comfort Park Avenue Hardware



Comfort Park Avenue Bases



Comfort Bases



Comfort Park Avenue

PARTS LIST: (Quantity for one 6' bench)

QTY	ITEM
2	2" x 4"x 6' Bench Slats with 6 anchor holes
5	2" x 4"x 6' Bench Slats with 3 anchor holes
3	Pre Drilled Bench Supports
27	1/4 x 3 1/2 Zinc Plated Lag Screws
27	Zinc Plated Washers

TOOLS NEEDED FOR INSTALLATION:

Socket set with a 7/16" Socket

INSTALLATION INSTRUCTIONS:

1. Check Parts list to verify all items.
2. Place washers on the zinc plated lag screws and start them in the pilot holes (on the bench slats).
3. Run the lag screws through the pilot holes in the slats letting them extend through approximately 1/4".
4. Place the slats on the supports and line up the pre drilled holes in the supports. Start with one slat on the front and then one slat on the top (to allow you to get the bench square). Finish with the remaining bench supports in any order.
5. Using the 7/16" socket tighten the lag screws securing the slats and the supports.
6. DO NOT OVERTIGHTEN THE LAG SCREWS! THIS MAY CAUSE THE PLASTIC BENCH SUPPORTS TO STRIP OUT!



www.jayhawkplastics.com

8 Foot Comfort Park Avenue



Hardware



Cedar Slats



Recycled Plastic Bases



8ft Comfort Park Avenue

PARTS LIST: (Quantity for one 8' bench)

QTY	ITEM
2	2" x 4"x 8' Bench Slats with 8 anchor holes
5	2" x 4"x 8' Bench Slats with 4 anchor holes
4	Pre Drilled Bench Supports
36	1/4 x 3 1/2 Zinc Plated Lag Screws
36	Zinc Plated Washers

TOOLS NEEDED FOR INSTALLATION:

Socket set with a 7/16" Socket

INSTALLATION INSTRUCTIONS:

1. Check Parts list to verify all items.
2. Place washers on the zinc plated lag screws and start them in the pilot holes on the bench slats.
3. Run the lag screws through the pilot holes in the slats letting them extend through approximately 1/4".
4. Place the slats on the supports and line up the pre drilled holes in the supports. Start with one slat on the front and then one slat on the top (to allow you to get the bench square). Finish with the remaining bench supports in any order.
5. Using the 7/16" socket tighten the lag screws securing the slats and the supports.
6. DO NOT OVERTIGHTEN THE LAG SCREWS! THIS MAY CAUSE THE PLASTIC BENCH SUPPORTS TO STRIP OUT!



www.jayhawkplastics.com