

8 Foot Colonial



Hardware



Recycled Plastic Bases



Cedar Slats



8ft Colonial

PARTS LIST: (Quantity for one 8' bench)

QTY	ITEM
4	2" x 6"x 8' Bench Slats
4	Pre Drilled Bench Supports
32	1/4 x 3 1/2 Zinc Plated Screws
32	Zinc Plated Washers

TOOLS NEEDED FOR INSTALLATION:

Socket set with a 7/16" Socket

INSTALLATION INSTRUCTIONS:

1. Check parts list to verify all items.
2. Assemble on a flat, level surface.
3. Place washers on the zinc plated lag screws and start them in the pilot holes (on the bench slats).
4. Run the lag screws through the pilot holes in the bench slats letting them extend through approximately 1/4".
5. Place the slats on the supports and line up the pre drilled holes in the supports. Start with one slat on the seat and one slat on the back to allow you to get the bench square. Finish with the remaining bench supports in any order.
6. Using the 7/16" socket tighten the lag screws securing the slats and supports.
7. **DO NOT OVERTIGHTEN THE LAG SCREWS!! THIS MAY CAUSE THE PLASTIC BENCH SUPPORTS TO STRIP OUT!**



www.jayhawkplastics.com