

4 Foot Contour



Cross Support Rods



Hardware



4 ft. Contour

PARTS LIST: (Quantity for one 4' bench)

QTY	ITEM
8	2" x 4"x 4' Bench slats
2	Powder-coated structural steel frames
16	3/8-16 x 2 1/4 Carriage bolts
16	3/8-16 Nylon Lock Nuts

TOOLS NEEDED FOR INSTALLATION:

Socket Set with 9/16" Socket Wrench

INSTALLATION INSTRUCTIONS:

1. Check and verify that all items are included.
2. Assemble on a flat, level surface.
3. Space the three frames so that the holes in the slats line up with the holes in the frames.
4. Attach the slats starting at the bottom and working up the backside of the bench to the top slat.
5. Place the carriage bolt down through the slat, through the frame and place a lock nut on the underside of the frame.
6. Tighten with a socket wrench making sure that the frame and the boards are squared away.
7. Complete the process over until all boards have been attached to the frames.



www.jayhawkplastics.com

6 Foot Contour



Hardware



Bases



6 ft. Contour

PARTS LIST: (Quantity for one 6' bench)

QTY	ITEM
8	2" x 4" Bench Slats
3	Powder-coated structural steel frames
24	3/8-16 x 2 1/4 Carriage bolts
24	3/8-16 Nylon Lock Nuts

TOOLS NEEDED FOR INSTALLATION:

Socket Set with 9/16" Socket Wrench

INSTALLATION INSTRUCTIONS:

1. Check and verify that all items are included.
2. Space the three frames so that the holes in the slats line up with the holes in the frames.
3. Attach the slats starting at the bottom and working up the backside of the bench to the top slat.
4. Place the carriage bolt down through the slat, through the frame and place a lock nut on the underside of the frame.
5. Tighten with a socket wrench making sure that the frame and the boards are squared away.
6. Complete the process over until all boards have been attached to the frames.



www.jayhawkplastics.com

8 Foot Contour



Hardware



Bases



Seat/Back Support
brackets

PARTS LIST: (Quantity for one 8' bench)

QTY	ITEM
8	2" x 4"x 8' Bench Slats
4	Powder-coated structural steel frames
32	3/8-16 x 2 1/4 Carriage bolts
32	3/8-16 Nylon Lock Nuts

TOOLS NEEDED FOR INSTALLATION:

Socket Set with 9/16" Socket Wrench

INSTALLATION INSTRUCTIONS:

1. Check and verify that all items are included.
2. Assemble on a flat, level surface.
3. Space the three frames so that the holes in the slats line up with the holes in the frames.
4. Attach the slats starting at the bottom and working up the backside of the bench to the top slat.
5. Place the carriage bolt down through the slat, through the frame and place a lock nut on the underside of the frame.
6. Tighten with a socket wrench making sure that the frame and the boards are squared away.
7. Complete the process over until all boards have been attached to the frames.



www.jayhawkplastics.com